


BUSBARS

for S, SL and T miniature circuit breakers




Busbars fork type


CROSS SECTION (mm ²)	BUSBAR CURRENT START OF BUSBAR/ MIDDLE INFEEED	NUMBER OF POLES	ITEM NO.	WEIGHT g / EACH	PACKING UNIT
----------------------------------	--	-----------------	----------	-----------------	--------------

3-phase

10	63	6	G31006	37	25
10	63/100	9	G31009	60	25
10	63/100	12	G31012	84	25

16	80	6	G31606	52	20
16	80/130	9	G31609	87	20
16	80/130	12	G31612	119	20

 Busbars cannot be cut to length!




Busbars fork type

3-phase for left-hand RCCB installation in the distribution board (N omitted)

10	63	11	G31011S	82	25
16	80	11	G31611S	117	20

3-phase for right-hand RCCB installation in the distribution unit

16	80	11	G31611	108	20
----	----	----	---------------	-----	----

 Busbars cannot be cut to length!